



Aluminium Nosing fitting recommendations for following profiles:

SKU: AL-CAR-77, A4-CAR-76, A1-CAR-59, AAI-57

Please note, the following is a recommendation only and should be used as a guide. As every stair surface and substrate differ, common sense should prevail when fitting. Gorilla Fix All Turbo adhesive should be ordered with purchase.

Fitting to wooden, concrete, tile and waterproof stairs:

- Clean stair thoroughly from any grime, oil, etc.
- Clean underside of stair nosing with Product Code 19389 Gorilla 696 Surface Activator - (Adhesion Promoter) or acetone
- Place zigzag pattern of adhesive (Product code 20311 Gorilla Fix All TURBO) on underside of nosing and stick down ensuring adhesion along the entire length.
- Clean up any excess adhesive with acetone and a plastic scraper.

(Please note if stair surface is uneven the use of weights, i.e bricks on top of nosing can be used until adhesive cures)

Disclaimer

- Please note, these are recommendations only and should be used as a guide only.
- Slip Proof NZ aluminium nosing's adhere to multiple industry standard adhesives. It is up to the installer to determine the suitability of any products.
- Slip Proof NZ will not accept any liability for failures due to installation error or those that aren't a Slip Proof NZ Ltd aluminium stair nosing direct fault.